

KRAIBURG MONTA

prerequisites:




concrete:

- minimum 10 cm thick
- no holes
- no elevations


mats:

even temperature:
minimum 5° C to maximum
30° C (store according to initial
temperature)




You will need this:


measuring:




marking:



cutting:



drilling and installing:



KRAIBURG fastening elements:

- nail plugs \varnothing 10 x 80 mm - A2
- washers \varnothing 30 mm - A2

(or fastening elements with at least the same resistance and durability)




Guidelines for trafficability:

MONTA can be driven on up to maximum 10 % slope with standard equipment such as farm yard loader or tractor with authorized pneumatic tyres at the recommended inflation pressure up to max. 4 bar.



Notice:

- maximum half walking speed (about 2 km/h)
- only drive straight / do not steer any radius
- do not accelerate or brake on the mat




The mat edges must be protected at the beginning and at the end of the mat surface.

1 Lay out mats




distance at the mat edges:
approx. 1 cm

approx. 1 cm



the arrows designating "DOWN"
point downhill


2 Adaptation



if necessary,
cut mats to fit

tips for cutting:

- moisten the blade lightly
- bend the mats / pull them slightly apart
- possibly lay a board underneath - score - cut




tip: use pliers for pulling
small pieces apart




3 Fasten


mat size 65 x 200 cm:
at least 9 fastenings / mat




mat size 130 x 200 cm:
at least 10 fastenings / mat





Fasten at the points specified above:




drill





pound the plastic
plugs in flush



pound in nails and washers until
they are seated evenly fast and are
slightly countersunk



i tip: check to see if the fastening can be felt with a flat object made of metal (e.g. hammer) by sliding it over the fastening. If it can be felt, pound it in deeper!



a small gap
should
be visible

! do not pound in too strongly!

no tension
should develop,
mat should
not bulge!

